






# Señales de EEG


# Bases de Datos

Melanie Álvarez  
5 de agosto de 2024

## Bases de Datos

	<b>CHB - MIT</b>	Dataset of 24 subjects, all human females and males. Dataset was recorded with the help of 23 electrodes placed on scalp of epilepsy patients
	<b>Bonn</b>	The dataset comprises five subsets, where each one contains 100 single-channels recording
	<b>TUH</b>	The dataset consists of both generalized and focal seizure.
	<b>Freiburg</b>	This dataset was collected from the invasive EEG recordings of 21 patients suffering from medically intractable focal epilepsy.
	<b>BERN Barcelona</b>	This dataset comprised EEG recordings derived from five pharmacoresistant temporal lobe epilepsy patients. This dataset is good for the seizure localization purpose.

# CONTENIDO



01

CHB - MIT



02

TUH



03

Bonn  
University



04

BERN  
Barcelona


# CHB - MIT

22 individuos  
pediátricos con crisis  
epilépticas  
intratables

Las señales muestran 256  
muestras por segundo con  
16bits de resolución.

- Señales agrupadas en 23 casos.
- Cada caso tiene entre 9 y 42 archivos .EDF.
- Cada archivo tiene entre 23 y 26 señales EEG.

Se utilizó el sistema  
internacional 10-20 de  
posiciones y nomenclatura  
de electrodos de EEG.



664 archivos  
.EDF

129 archivos  
registran  
ataques de  
epilepsia

<https://physionet.org/content/chbmit/1.0/#files-panel>

En total, se  
presentan 198  
episodios  
epilépticos

Data Sampling Rate: 256 Hz

\*\*\*\*\*

Channels in EDF Files:

\*\*\*\*\*

Channel 1: FP1-F7

Channel 2: F7-T7

Channel 3: T7-P7

Channel 4: P7-O1

Channel 5: FP1-F3

Channel 6: F3-C3

Channel 7: C3-P3

Channel 8: P3-O1

Channel 9: FP2-F4

Channel 10: F4-C4

Channel 11: C4-P4

Channel 12: P4-O2

Channel 13: FP2-F8

Channel 14: F8-T8

Channel 15: T8-P8

Channel 16: P8-O2

Channel 17: FZ-CZ

Channel 18: CZ-PZ

Channel 19: P7-T7

Channel 20: T7-FT9

Channel 21: FT9-FT10

Channel 22: FT10-T8

Channel 23: T8-P8

File Name: chb01\_01.edf

File Start Time: 11:42:54

File End Time: 12:42:54

Number of Seizures in File: 0

File Name: chb01\_02.edf

File Start Time: 12:42:57

File End Time: 13:42:57

Number of Seizures in File: 0

File Name: chb01\_03.edf

File Start Time: 13:43:04


File End Time: 14:43:04

Number of Seizures in File: 1

Seizure Start Time: 2996 seconds

Seizure End Time: 3036 seconds





<https://physionet.org/lightwave/?db=chbmit/1.0.0>



# CONDICIONES DE LOS PACIENTES

Subjects were monitored for up to several days following withdrawal of anti-seizure medication in order to characterize their seizures and assess their candidacy for surgical intervention.



# The Temple University Hospital (TUH)

Los datos se recogieron de los registros de archivo del Hospital de la Universidad de Temple (TUH).



14 años de información

Las señales de EEG fueron convertidas a formato EDF y se asignaron valores numéricos a los registros







El corpus se definió con una estructura jerárquica de árbol de archivos al estilo Unix.

# Propuesta de valor


“Typically, “research-grade” data is created by tightly controlling as many external factors as possible. In contrast, “clinical-grade” data is inherently heterogeneous with respect to those same external factors. [...] Algorithms that must be sufficiently robust to function under a plurality of conditions must be trained with data that is sufficiently heterogeneous.”

—Obeid y Picone (2016)



El 51% de los sujetos eran mujeres; las edades comprenden entre menos de 1 año y más de 90 años.

En promedio, cada sesión presentó 31 canales de EEG



El corpus completo comprende 16.986 sesiones de 10.874 sujetos únicos. Cada una de estas sesiones contiene al menos un archivo EDF y un informe del médico.




**CLINICAL HISTORY:** 70 year old right handed woman with new onset nocturnal convulsive movements with foaming at the mouth, hypertension, and anxiety.

**MEDICATIONS:** Norvasc, Simvastatin, Nexium, Folate Acid.

**INTRODUCTION:** Digital video EEG was performed in lab using standard 10-20 system of electrode placement with 1 channel EKG. Hyperventilation and photic stimulation were completed.

**DESCRIPTION OF THE RECORD:** In wakefulness, the background EEG includes generous beta and an 11-Hz alpha rhythm. Hyperventilation produces an increase in amplitude of the background.

●  
●  
●



The data available from the NEDC web site is offered free and without restriction, except for a few conditions below that you must abide by:

- (1) The user should acknowledge the provider of this data using the publication listed in the documentation included with the specific corpus (typically found in the AAREADME file).
- (2) The user will not release data to a third party or redistribute the data. Please have the third party contact us directly by sending an email to [help@nedcdata.org](mailto:help@nedcdata.org).
- (3) The user agrees that no attempts will be made to re-identify the subjects, who have been anonymized in this distribution.
- (4) The user will not use the data for malicious purposes. This data can be used for research and technology development, but not for uses beyond these broad classifications.
- (5) The data recipient will delete the data from all computer systems when finished with the data.

Contact Information:

Your Legal Name	
Your Institutional Affiliation (Complete Name – No Abbreviations)	
Your Personal Post Office Address At The Above Institution	
Telephone Number (Include Your Country Code)	
Email Address	



## CONDICIONES DE LOS PACIENTES

A wide range of medications and medical conditions. Unsurprisingly, the most common listed medications were anti-convulsants such as Keppra and Dilantin, as well as blood thinners such as Lovenox and heparin.

# BONN University

Cinco sets de 100  
segmentos de señales EEG  
de 23.6 segundos

Los conjuntos A y B consistían  
en segmentos de grabaciones  
de EEG realizadas en cinco  
voluntarios sanos

Los conjuntos C, D y E  
procedían de un archivo de  
EEG de diagnóstico  
prequirúrgico.



# BONN University

SET A Z.zip with Z000.txt - Z100.txt (564 kB)

SET B O.zip with O000.txt - O100.txt (611 kB)

SET C N.zip with N000.txt - N100.txt (560 kB)

SET D F.zip with F000.txt - F100.txt (569kB)

SET E S.zip with S000.txt - S100.txt (747kB)

-56

-50

-64

-91

-135

-140


-134

-114


-115

<https://www.ukbonn.de/epileptologie/arbeitsgruppen/ag-lehnertz-neurophysik/downloads/>


# BERN Barcelona




Grabaciones intracraniales  
EEG de pacientes con  
epilepsia fármacorresistente



El resto de canales se  
clasificaron como  
no-focales



Se definió como señal EEG focal a  
aquellas que detectaban los  
primeros cambios de señal de  
EEG ictales



Se seleccionaron aleatoriamente  
3750 pares de señales x e y del  
conjunto de todas las señales en  
canales focales y no-focales de EEG.

# BERN Barcelona

Data F Ind 1 750.zip  
Data F Ind 751 1500.zip  
Data F Ind 1501 2250.zip  
Data F Ind 2251 3000.zip  
Data F Ind 3001 3750.zip  
Data N Ind 1 750.zip  
Data N Ind 751 1500.zip  
Data N Ind 1501 2250.zip  
Data N Ind 2251 3000.zip  
Data N Ind 3001 3750.zip

Cada archivo Zip contiene 750 archivos de texto individuales, cada archivo de texto contiene un par de señales individuales.

-23.584467,	22.621477
-20.180197,	26.547081
-16.631811,	28.431639
-12.762078,	30.098673
-10.451992,	30.030939
-9.788496,	27.864071
-9.092120,	27.279987

## CONDICIONES DE LOS PACIENTES

All five patients had longstanding pharmacoresistant temporal lobe epilepsy and were candidates for epilepsy surgery and underwent long-term intracranial EEG recordings.